



IB Diploma Programme Exam Mode

For the Diploma Programme of the International Baccalaureate (IB), the HP Prime Graphing Calculator is allowed for exam use. The HP Prime needs to be set in Exam Mode. This document helps you set the right mode and be prepared for the exam properly.

More information on the HP Prime?
<http://www.hp-prime.com>

- **Note:** Candidates must upgrade their Prime to the latest operating system to use the “Exam Mode” properly. Primes which have not been updated and put into the correct “Exam Mode” are not allowed in the examinations. Primes must be put into “Exam Mode” immediately before the examination. If done earlier, a candidate must not have access to the calculator between the time it is put into “Exam Mode” and the examination. “Timeout” must be set for at least the duration of the examination.

The following options in “Exam Mode” mode must be ticked.

- Erase memory
- Blink LED

The following options in “Exam Mode” mode must be ticked and therefore blocked.

- PredX
- PredY
- Triangle Solver
- Linear Explorer
- Quadratic Explorer
- Trig Explorer
- Geometry
- Advanced Graphing
- User Apps
- Physics
- CAS
- Notes and Programs
- New Notes and Programs
- Vector

- **Note:** A complete setup exam mode file can be found on www.hp-prime.com. Simply download this to your Exam Mode folder (Documents/HP Connectivity Kit/Content/Exam mode) to immediately open, distribute and start it.

